

Ausschließlich kompatibel mit folgenden Handsendern

Keine anderen Modelle oder Hersteller kompatibel, auch wenn gleiche Frequenz!

Hersteller	Frequenz (MHz)	Modell
ADYX	433,92	Alize EM2C, Alize EM4C
Aeterna	433,92	TX433 (1-/ 2-/ 3-/ 4 -Tasten)
Allmatic	433,92	Europe Auto Army2, Army1, Army4 MX1, MX2, MX4
Alltronik	433,92	S429_1, S429_2, S429_4, S429_M, S425 stellen Sie sicher dass Ihr original wirklich 433,92 MHz hat
Ansonic	433,92	SA 434-1E, SA434-2E, SA434-3E, SA434-4E SA434-1Mini, SA434-2Mini, SA434-2Midi
Avidsen	433,92	100601 micromark MM23164 104505 100951, 100955, 100550, 100400
Bft	433,92	TE01, TE02, TE04
Belfox	433,92	DHS433-1, DHS433-2, DHS433-4 (DIP-Schalter Version) DHS 433,92 (7733) (DIP-Schalter Version)
Beninca	433,92	LOT1W, LOT2W, LOT4W LOT2WMS T2WK, T4WK LOTX1W, LOTX2W, LOTX4W TO.GO2WP, TO.GO4WP, TO.GO2WK, TO.GO4WK
Berner	433,92	SKX1MD, SKX2MD, SKX3MD, SKX4MD SKX1KD, SKX2KD, SKX4KD, SKX6KD SKX1DL, SKX2DL, SKX3DL, SKX4DL SKX1LC, SKX2LC, SKX3LC, SKX4LC SKX1SL, SKX2SL, SKX3SL, SKX4SL SKJ SKX1WD, SKX2WD, SKX4WD, SKX11WD, SKX22WD, SKX44WD
Beside	433,92	BEZAP, HIT
CAME	433,92	T432, T434, TOP432A, TOP434A, TOP432, TOP432NA, TOP434NA TOP432M, TOP434M TAM432SA TOP432SA Twin2, Twin4
Cardin	433,92	S476 TX2, S476 TX4 Genius 433 2, Genius 433 3, JA400 TM433, JA401 TM433
Casit	433,92	ERTS92B, ERTS92T ERTS20DB, ERTS20DQ ERTS476D, ERTS476Q TXS1, TXS2, TXS3, TXS4, TXS6 ERTS97B, ERTS97T
Celinsa	433,92	S10 1, S10 2, SAW1, SAW2
Centurion	433,92	Classic, Smart, Smart2

CDS	433,92	433, 433 2
CPS	433,92	TCP3, CPS, Jolly 4
		CPS1 TCP3, CPS2 TCP3, CPS4 TCP3
		EM1CV, EM2CV, EM4CV
DEA	433,92	433 1, 433 2, 433 4
		Genie
		Punto S2
		Mio TD2, Mio TD4
Delma	433,92	Mizard 300 1, Mizard 300 2, King
		Mizard 433 1, Mizard 433 2
		King 433 2
Dickert	433,92	MAHS433-01, MAHS433-04
		S10-433A1L00, S10-433A4L00, S20-433A1L00, S20-433A4L00, S20-433A1000, S20-433A4000
		S5-433-A2L00, S5U-433-A2L00
Doormatic	433,92	SAW
Dorma	433,92	HS, HS43 1E, HS43 2E, HS43 3E, HS43 4E
		MAHS
Ducati	433,92	TSAW1, TSAW2, TSAW3, TSAW4, 124
		Elbert
		Rondy
		TPR10-A, TPR20-A
		TE2
Elbe	433,92	501, 502, 504
		502a, 504a
Elka	433,92	SKX1MD, SKX2MD, SKX3MD, SKX4MD
		SKX1KD, SKX2KD, SKX4KD, SKX6KD
		SKX1DL, SKX2DL, SKX3DL, SKX4DL
		SKX1LC, SKX2LC, SKX3LC, SKX4LC
		SKX1SL, SKX2SL, SKX3SL, SKX4SL
		SKJ
		SKX1WD, SKX2WD, SKX4WD, SKX11WD, SKX22WD, SKX44WD
Erone	433,92	SETDS39433E2, SETDS39433E4
Fadini	433,92	433 2M, Astro43_2m
		Astro433-2, Astro433-4, Astro43-2, Astro43-4
Ferport	433,92	Tac1, Tac2, Tac4, Tac1k, Tac2k, Tac4k, Tac2kr
GFA	433,92	SKX1MD, SKX2MD, SKX3MD, SKX4MD
		SKX1KD, SKX2KD, SKX4KD, SKX6KD
		SKX1DL, SKX2DL, SKX3DL, SKX4DL
		SKX1LC, SKX2LC, SKX3LC, SKX4LC
		SKX1SL, SKX2SL, SKX3SL, SKX4SL
		SKJ
		SKX1WD, SKX2WD, SKX4WD, SKX11WD, SKX22WD, SKX44WD
Gibidi	433,92	Open TMB 433, Open TMQ 433, Open OUT 2, Open OUT 4
Gulliver	433,92	MDW 2E
Hauss	433,92	Pocket 3750-1, Pocket 3750-2, Pocket 3750-4
JAY	433,92	UBE1x1 SL1
		UBET 11, UBET 21, UBET 31, UBET 41, UBET 61A
Label	433,92	RJW/1E, RJW/2E, RJW/4E, RJW/12E
		MDW/1E, MDW/2E

Lince	433,92	LR 2035
Marantec	433,92	Digital 302, Digital 304, Digital 313, Digital 321, Digital 323
		Digital 211, Digital 212, Digital 221, Digital 222, Digital 231
MA System	433,92	MA TX1, MA TX2, MA TX3
Meissner/ Mischler	433,92	LW433-1, LW433-2, LW433-4
		Pocket 1, 2, 4 (3750)
Monseigneur	433,92	ARC2, ARC4
		TDR 400 3845, TDR 400 3846, TDR 400 3847
		T1SAW433, T2SAW433, T4SAW433
Nice	433,92	FLO01, FLO02, FLO04
		Very VE, SM2 Smilo
Nologo	433,92	ECO DIP
		BIT NT1, BIT NT2, BIT NT4
Novoferm	433,92	HS, HS43 1E, HS43 2E, HS43 3E, HS43 4E
		MAHS
OG	433,92	OG62, OG64
O&O	433,92	T-COM DS 4-2, T-COM DS 4-4
Openout	433,92	TMQ 433 2, TMQ 433 4
Portamatic	433,92	MPH01, MPH02
Prastel	433,92	MPSTF2E, MPSTF4E
Proem	433,92	ER2C4ACM, ER4C4ACM
Proget	433,92	ETY 433N2, ETY 433N4
		EMI433-N2
Proteco	433,92	TX433
		Euromatic
		Hit
Quasar	433,92	433 Tango Slim Bleu
Roma	433,92	Silento
SEA	433,92	SMART433 TX2 DIP, SMART 433 TX3 DIP
		SMART 433 TX2 Copy, SMART 433 TX3 Copy
SEAV	433,92	Behappy S1, Behappy S2, Behappy S3
		Be Easy TX, Be Easy Murale
		BeSmart S2, BeSmart S4
		BeFree S1
Securvera	433,92	SV R2C
		SV R4C
Serai	433,92	OG/52, OG/54, OG/82, OG/84
		OG/28, OG48, OG/62, OG/64
		OG/2, OG/4
Sice	433,92	TX4 Clack Bigfoot
Siebau	433,92	HS, HS43 1E, HS43 2E, HS43 3E, HS43 4E
		MAHS
Siminor	433,92	ER2C4ACM, ER4C4ACM, ER2C4ACS, ER4C4ACS
SMD	433,92	LW433-1, LW433-2, LW433-4 (nur Modelle mit AM Funk)
Startec	433,92	TXQ2
Telcoma	433,92	Tango 2 SW, Tango 4 SW
		Tango Blue 2, Tango Blue 4
		Tango Bleu 2, Tango Bleu 4
		Tango 2 Slim, Tango 4 Slim

Tau	433,92	250 Slim, 250K Slim, 250K Slim C
		250TXD2, 250TXD4
		250BUG2, 250BUG4
Tecnomatic	433,92	TQ433
Tedsen/ Teletaster	433,92	SKX1MD, SKX2MD, SKX3MD, SKX4MD
		SKX1KD, SKX2KD, SKX4KD, SKX6KD
		SKX1DL, SKX2DL, SKX3DL, SKX4DL
		SKX1LC, SKX2LC, SKX3LC, SKX4LC
		SKX1SL, SKX2SL, SKX3SL, SKX4SL
		SKJ
TKC	433,92	TSAW433
Torag	433,92	S429 1, S429 2, S429 4
Tormatic	433,92	HS, HS43 1E, HS43 2E, HS43 3E, HS43 4E
		MAHS
Trema	433,92	TO93TV1, TO93TV2, TO93TV4
Tubauto	433,92	Digital 101 433
Visonic	433,92	WT 100, WT 100A, WT101, WT 101 A
		WT 104, WT 201, WT 201 A, WT 201 WP, WT201 AWP
VSEG	433,92	CR Slim
Waine-Dalton	433,92	S429-1, S429-2, S429-4, S429-mini
Wecla	433,92	433, 433 2