



Handsender Jane V

Frequenz: 433,92 MHz - 868,3 MHz
Codierung: Fest-Code
Kanäle: 4
Energieversorgung: Lithium Batterie CR2032
Arbeitstemperatur: -40°C - +50°C



- Geben Sie Handsender niemals in Kinderhände
- Die Handsender dürfen ausschließlich von Personen bedient werden die mit der Anlage vertraut sind und in deren Funktion eingewiesen sind
- Das Anlernen der Handsender muss stets in der Nähe des Torantriebs vorgenommen werden. Verwenden Sie hierzu ausschließlich Originalteile
- Schützen Sie den Handsender vor Witterung wie Regen, Schnee, Sonneneinstrahlung oder auch Staub, ansonsten kann die Funktion des Senders beeinträchtigt werden
- Zum Wechseln der Batterie lösen Sie bitte die Schraube auf der Rückseite des Handsenders
- Der Originalhandsender und der Jane V müssen im gleichen Frequenzbereich liegen.


Programmierung:

Hinweis: Bitte führen Sie die Schritte sorgfältig und aufmerksam durch.

1. Drücken und Halten Sie die Taste 1 und 2 (siehe Tastenbelegung in oben gezeigter Abb.) bis die grüne LED des Handsenders anfängt zu blinken.
2. Drücken und Halten Sie nun die Handsendertaste gedrückt, die Sie einlernen wollen und halten Sie Ihren Originalhandsender und den Jane V-Handsender wie in einer der unten aufgelisteten Abbildungen aneinander.
3. Die LED wird nun viel schneller blinken, da der Jane V-Handsender die passende Codierung sucht und empfängt.
4. Danach halten Sie die Taste an Ihrem Originalhandsender gedrückt, welche die Codierung übertragen soll.
5. Wenn der Jane V-Handsender nun Ihren Originalhandsender erfolgreich angenommen hat, wird die LED für einen Moment dauerhaft blinken und die LED erlischt eine kurze Zeit später. Der Handsender ist nun eingelernt.
6. Wenn Sie eine neue Taste einlernen wollen, wiederholen Sie die nochmal alle oben aufgeführten Schritte in der Reihenfolge.

Sollte der Programmiervorgang nicht richtig funktioniert haben, leiten Sie bitte folgende Schritte ein:

- Wiederholen Sie den Vorgang und versuchen Sie hierbei die beiden Handsender in einer anderen Position wie unten aufgelistet aneinander zu halten.
- Wenn der Einlernvorgang bis zum Ende richtig funktioniert hat, aber die Codierung nicht übertragen wurde, leiten Sie eine erneute Duplizierung ein, wo Sie zwischen den Handsendern 1/2 cm Platz zu lassen.
- Wechseln Sie die Batterie Ihres Originalhandsenders. Eine leere Batterie kann die Codierung nicht vollkommen übertragen.



Warranty: 24 months – Manufacturing and technology 100% made in Italy – Patented product

Vereinfachte EU-Konformitätserklärung (CE)

The undersigned Luigino Pellattiero, legal representative of ITALFILE srl, declares that the remote control JVxxx-2/JVxxx-4, manufactured in 2011 was assembled in compliance with the following standards:
Directive 2004/108/CE – know as the Electromagnetic Compatibility Directive
Directive 2002/95/CE – known as the RoHS Directive – And therefore complies with current standards.
Luigino Pellattiero – Vincenza, 1.10.2011




Schartec
eine Marke der bau-shop-24 GmbH
Fritz-Müller-Strasse 119
73730 Esslingen



Remote Control Jane V

Frequency: 433,92 MHz - 868,3 MHz
Encryption: FIXED-Code
Channels: 4
Energy supply: Lithium battery 3v (CR2032)
Working temperature: -40°C - +50°C



- Keep remotes out of reach of children.
- Remote controls may only be operated by persons who are familiar with the system and have been instructed in their function.
- Coding in remote controls must always be carried out within the vicinity of the door operator. Use only original parts.
- Protect remotes from rain, snow, sunlight or dust, otherwise the function of the transmitter may be impaired
- To replace the battery, unscrew the screws on the back of the remote.
- The original remote control and the pairing Jane V remote must have the exact same frequency range.


Programming:

Note: Please follow the steps below careful and attentively.

1. Press and hold down the buttons 1 & 3 (as in the model above) simultaneously till the green LED flashes.
2. Press and hold down the button you want to code whilst holding both remotes together as shown in the pictures below.
3. The LED of the Jane V will now blink faster, because the remote control is searching for the fitting code to copy.
4. Afterwards press the button on your original remote, which can send the right coding to inherit.
5. If step 4 has been carried out correctly then the LED on the Jane V will glow for a moment and switch itself off afterwards.
The remote control is now encoded.
6. For each new coding please repeat the procedure again in the right sequence.

If the duplication procedure didn't work as expected, please follow the steps below:

- Try to repeat the procedure by holding the remotes in different positions.
- If the Jane V has confirmed the copied signal but is still not working please repeat the procedure but hold the remotes about 1/2 cm apart from each other.
- Please exchange the battery in your original remote. An empty battery wont be able to send out the right coding onto the Jane V.



Simplified EU Declaration of Conformity (CE)

Warranty: 24 months – Manufacturing and technology 100% made in Italy – Patented product
Compliance statement

The undersigned Luigino Pellattiero, legal representative of ITALFILE srl, declares that the remote control JQxxx-2/JQxxx-4, manufactured in 2011 was assembled in compliance with the following standards:

Directive 2004/10/CE – know as the Electromagnetic Compatibility Directive
Directive 2002/95/CE – known as the RoHS Directive – And therefore complies with current standards.
Luigino Pellattiero – Vincenza, 1.10.2011

